Operating Equipment in Enhanced Classrooms

Use the touch-screen control panel (see picture) to operate the projector and to select the components to project.

To power the system on:
From the Main Menu screen, press System On

Turn on Projector:
Touch the Projector Icon then, PWR ON.
Touch the Main Menu button to return to the main menu

Select the desired component to projector:
To **project the Computer**, touch the computer icon. Turn the computer and the computer monitor on (if necessary) by pressing their power buttons and operate the computer and   you normally would.

To **project a Laptop**, plug the laptop cable into the VGA port on your laptop. Touch the Computer Icon on the touch screen. Operate the laptop as you normally would.

To **project a DVD or Blu-Ray**, touch the Blu-Ray icon. Operate the DVD or Blu-Ray as you normally would.

To **project the document presenter**, touch the Document Presenter icon. Turn the document presenter on by pressing its Power button located on the right side of the base.

To **project a tablet** (Android or iPad), touch the Tablet PC icon. Connect the tablet to the white HDMI cable. An adapter may be needed depending on the device being used.

Volume Control:

Volume control is on the screen of each component. Raise and lower the volume using the up and down arrows on each component screen, as desired.

When Finished:

Turn the projector off by touching System Off on the main menu screen OR touch the Projector Icon, then PWR OFF.
Turn the document presenter off.