Operating Equipment in Enhanced Classrooms

Use the remote control for projector power and the touch-screen control panel to select the components you wish to project. The three components are computer, laptop, and document presenter.

Projector Power:

Use the REMOTE CONTROL labeled PROJECTOR – press the RED button once.

Select the desired component to project:

To <u>project the Computer</u>, touch Computer. Turn the computer and the computer monitor on, if necessary, by pressing their power buttons.

To <u>project a Laptop</u>, touch Laptop. Connect the laptop to the cable labeled laptop.

To <u>play a DVD</u> - use the DVD drive in the computer

To <u>project the Document Presenter</u>, touch Doc Cam. Turn on the document presenter by pressing its Power button.

Volume Control:

Touch the Volume icon to raise or lower the volume.

When Finished:

Turn off the projector by pressing the RED button on the REMOTE CONTROL labeled PROJECTOR <u>2 times</u>.
Turn off the document presenter.