

To Power ON Projector - Press ON using light grey Sharp remote

To project PC - Press "A" on Kramer Switcher

To project Doc Cam - Press "B" on Kramer Switcher

To project Microscope - Press "C" on Dark Grey Kramer Switcher

To play a DVD - use the DVD drive in the computer

Volume is controlled manually on the TOA amplifier (right hand side of instructor desk - bottom)

All inputs project through Input 1 on remote. If the projector is not displaying the image you selected, press Input 1 on the Sharp remote.

To Power OFF Projector - Press STANDBY 2 times