

To Power ON Projector - Use black remote labeled “projector” and press the RED button 1x

To project PC - Select “A” on Tan Switchbox

To project Laptop - Connect VGA cable to the laptop and select “B” on Tan Switchbox

To project Doc Cam - Press “C” on Tan Switchbox

To play a DVD - use the DVD drive in the computer

Volume is controlled manually on the TOA amplifier (left hand side of instructor desk - bottom)

All inputs project through Computer input on remote. If the projector is not displaying the image you selected, press Computer on projector remote.

To Power OFF Projector - Use black remote labeled “projector” and press the RED button 2x