

Operating Equipment in Enhanced Classrooms – T2

Use the Projector Remote (Sharp) to operate the projector and to select the components you wish to project

Turn on Projector:

Press the “On” button on the Projector Remote.

Select the desired component to project:

To project the Computer, press INPUT 2 on the Projector Remote.
Turn the computer and the computer monitor on if necessary by pressing their power buttons and operate the computer and you normally would.

To project a laptop, press INPUT 2 on the Projector Remote.
Turn on the laptop and connect the laptop cable (laying on the desk) to the laptop. Within 5 seconds, the laptop will project.

To project the document presenter, press INPUT 1 on the Projector Remote. Turn on the document presenter by pressing its Power button.

To project the DVD/VCR, press INPUT 3 on the Projector Remote.
Operate the DVD/VCR as you normally would.

Volume Control:

Adjust the volume by using the MASTER VOLUME CONTROL knob on the Amplifier.

When Finished:

Turn off the projector by pressing Standby (2 X) on the Projector Remote.
Turn off the document presenter.
Turn off the computer monitor. You may leave the computer on.

